

CONTENTS

	Preface	vii
Chapter 1	Introduction	1
1.1	A Revolution in Information Processing	1
1.2	The Learning Curve	2
1.3	Flash Memory Technology	3
1.4	Microcontroller Feature Set	5
Chapter 2	CPU Architecture	9
2.1	Overview	9
2.2	Harvard Architecture	9
2.3	Direct Addressing	10
2.4	Indirect Addressing	11
2.5	Reading Operands from Program Memory	16
2.6	Program Instruction Sequencing	19
2.7	The CPU and Its Status Bits	21
2.8	The Special Function Registers (SFRs)	23
	Problems	23
Chapter 3	Instruction Set	27
3.1	Overview	27
3.2	F/W Distinction	27
3.3	“BANKED” Option	30
3.4	Move Instructions	30
3.5	Single Operand Instructions	33
3.6	AND, OR, Exclusive-OR Instructions	35
3.7	Arithmetic Instructions	36
3.8	Conditional and Unconditional Branches	37
3.9	Conditional Skip Instructions	39
3.10	Subroutine Call and Return Instructions	40
3.11	Remaining Instructions	41
	Problems	41
Chapter 4	QwikFlash Target Board	44
4.1	Overview	44
4.2	QwikFlash I/O Circuitry	45
4.3	The QwikFlash Instrument	48
4.4	Debugging Support	48
Chapter 5	Program Development (P1 template)	51
5.1	Overview	51
5.2	Timer0 Operation	52
5.3	Program Structure	55
5.4	LoopTime Subroutine	55
5.5	BlinkAlive Subroutine	57
5.6	Macros	58
5.7	P1.asm Program	60
5.8	Free Tools	63
5.9	Assembly	64
5.10	Execution	65
	Problems	68
Chapter 6	Structured Assembly Preprocessor	71
6.1	Overview	71
6.2	Conditional Assembly vs. Execution	72
6.3	Structured Assembly Constructs	72
6.4	Condition Tests	74
6.5	SASM Input Parameters	74
6.6	SASM Installation and Execution	77
6.7	P1.asm Revisited	77
	Problems	81
Chapter 7	Alphanumeric Liquid-Crystal Displays (P2 template)	83
7.1	Overview	83
7.2	LCD Interface Alternatives	84
7.3	Initialization	86
7.4	Cursor-Positioning Codes	87
7.5	Display Strings	90
7.6	LCD Character Set	92
7.7	User-Defined Characters	94
7.8	Display Debugging Aid	97
7.9	P2.asm, A Display Template Program	100
	Problems	105
Chapter 8	Rotary Pulse Generators	108
8.1	Overview	108
8.2	RPG Resolution	108
8.3	RPG Functionality	109
8.4	RPG Subroutine	110
8.5	Rate-Sensitive RPG	111
	Problems	114
Chapter 9	Interrupts and Interrupt Timing	116
9.1	Overview	116
9.2	Interrupt Timing for Low-Priority Interrupts	117
9.3	Low-Priority Interrupt Structure	121
9.4	High-Priority Interrupt Structure	125
9.5	Critical Regions	127
9.6	External Interrupts	129
9.7	PORTB-Change Interrupts (Pins RB7:RB4)	130
	Problems	131
Chapter 10	Analog-to-Digital Conversion	134
10.1	Overview	134
10.2	Assignment of I/O Pins	134
10.3	ADC Output Format	136
10.4	ADC Characteristics and Use	138
10.5	Interrupt Control of the ADC	142
	Problems	142
Chapter 11	I/O Pin Considerations	144
11.1	Overview	144
11.2	Digital Output Pin Functionality	144
11.3	Digital I/O Circuitry	147
11.4	Input Considerations	150
	Problems	151
Chapter 12	LCD Screens (P3 template)	153
12.1	Overview	153
12.2	Pushbutton Entry	154
12.3	Screens Subroutine	156
12.4	P3.asm, A Screens Template Program	158
	Problems	167
Chapter 13	Time-Interval Measurements	169
13.1	Overview	169
13.2	Timer1 and Internal Measurements	169
13.3	DisplayMax Subroutine	172
13.4	Extended Internal Measurements	174
13.5	CCP1 and External Measurements	177
13.6	CCP1 and Internal Measurements	180
13.7	Extended External Measurements	180
13.8	Timer3 and CCP2 Use	181
13.9	Frequency Measurement	182
13.10	Temperature Measurement	183
	Problems	184

Chapter 14	Math Subroutines 186	Chapter 20	Miscellaneous Features 302
14.1	Overview 186	20.1	Overview 302
14.2	Multiplication 186	20.2	Configuration Bytes 303
14.3	Division 189	20.3	Oscillator Alternatives 305
14.4	Use of Multiplication/Division Subroutines 191	20.4	Supply Voltage 307
14.5	Retaining Resolution 191	20.5	Low-Voltage Detect (LVD) 308
14.6	Floating-Point Subroutines 195	20.6	Brownout Reset (BOR) 311
14.7	Use of Floating-Point Subroutines 197	20.7	Watchdog Timer (WDT) 311
14.8	Normalize Subroutine 198	20.8	Resets 314
	Problems 201	20.9	Battery-Powered Operation 317
		20.10	Timekeeping 320
Chapter 15	Serial Peripheral Interface for I/O Expansion 202	20.11	Data EEPROM Use 321
15.1	Overview 202	20.12	Parallel Slave Port (PSP) 323
15.2	SPI Functionality 202		
15.3	SPI Setup 203		
15.4	Output Port Expansion 206		
15.5	Input Port Expansion 206		
15.6	Multiple I/O Port Expansion 207		
15.7	DAC Output 210		
15.8	Temperature Input 212		
15.9	Master-Slave Interconnections 214		
	Problems 217		
Chapter 16	Output Time-Interval Control (P4 template) 219		
16.1	Overview 219		
16.2	External Control of Timing 220		
16.3	Periodic Interrupt Generator 223		
16.4	Fast Jitter-Free Square Wave Output 229		
16.5	General Jitter-Free Square Wave Output 232		
	Problems 238		
Chapter 17	SMBus/I²C for Peripheral Chip Access 241		
17.1	Overview 241		
17.2	SMBus/I ² C Specifications 242		
17.3	I ² C Bus Operation 242		
17.4	PIC18F452 Support for I ² C Bus Transfers 246		
17.5	I/O Expansion 246		
17.6	Low-Level I ² C Subroutines 249		
17.7	I/O Expander Code 253		
17.8	DAC Output 253		
17.9	Digital Thermometer 256		
17.10	An Example 257		
	Problems 266		
Chapter 18	UART 270		
18.1	Overview 270		
18.2	Waveforms and Baud-Rate Accuracy 270		
18.3	Baud-Rate Selection 273		
18.4	UART Data-Handling Circuitry 273		
18.5	UART Initialization 275		
18.6	UART Use 275		
	Problems 280		
Chapter 19	Programmed Peripheral Chips 281		
19.1	Overview 281		
19.2	PIC16C505 Overview 281		
19.3	Keypad Peripheral Interface 286		
19.4	Mainline Program and LOOPTIME Macro 289		
19.5	Detection of Key Presses 290		
19.6	KEYSWITCH State Machine 291		
19.7	UART Macro 293		
19.8	PIC16C505 Source File 293		
	Problems 300		

APPENDICES

Appendix A1 Assembly of the QwikFlash Board 327

A1.1	Preamble 327
A1.2	Microchip's ICD2 Module 328
A1.3	Parts List 328
A1.4	Construction Supplies Needed 328
A1.5	Soldering Technique 331
A1.6	Board Construction 331
A1.7	Flux Removal 337
A1.8	Performance Verification Before LCD Installation 337
A1.9	LCD Installation 338
A1.10	Performance Verification 338
A1.11	QwikBug Performance Verification 339

Appendix A2 Laboratory Development with the QwikProto Add-On Board 341

A2.1	Board and Parts 341
A2.2	Construction 343
A2.3	Constraints Placed on Pin Use 343
A2.4	Project Ideas 345
A2.5	The Author's Laboratory Stations 346

Appendix A3 Use of Structured Assembler with MPLAB™ User Interface by James Eubanks 349

A3.1	Installing SASM 349
A3.2	Setting up the Project 350
A3.3	Use of the QwikAddress Utility 350

Appendix A4 QwikBug Monitor Program by Burt Sims 351

A4.1	Introduction 351
A4.2	Resources Used 352
A4.3	Installation of QuikBug Using ICD2 Module 352
A4.4	Installation of QuikBug Using the P16PRO PIC Programmer 354
A4.5	QwikBug Verification 355
A4.6	Autostart Feature 356
A4.7	Command Keys 356
A4.8	Help Command (F1 or H) 356
A4.9	reseT Command (F2 or T) 356
A4.10	Load Command (F3 or L) 357
A4.11	Display Command (F4 or D) 358
A4.12	Break Command (F5 or B) 358
A4.13	Watch Command (F6 or W) 358
A4.14	Run Command (F7 or R) 360
A4.15	Step Command (F8 or S) 360
A4.16	Modify Command (F9 or M) 360
A4.17	Modifying QwikBug 361
A4.18	Acknowledgment 361

Appendix A5	QwikAddress and QwikPH Utilities	362	Appendix A9	Parts and Packages	395
A5.1	Overview	362			
A5.2	David Flowers' QwikAddress Utility	363	Appendix A10	Example of Course Organization and Lab Projects	396
A5.3	Chris Twigg's QwikPH Utility	364	A10.1	Course Calendar	396
			A10.2	Building a Laboratory	396
Appendix A6	Verification of Math Subroutines by Chris Twigg	369	A10.3	Lab Equipment	398
			A10.4	Assembly Coding vs. Structured Assembly Coding vs. C Coding	398
Appendix A7	Use of C Programming for the PIC18F452 by Mike Chow	371	A10.5	Ten Projects	399
Appendix A8	PIC18F452 Special Function Registers and Their Bits	391	Index		417